

## Australian Chemicals & Coatings Pty Ltd

ABN: 92 884 104 142

69 Quantum Close,  
Dandenong South VIC 3175

Ph: +61 (03) 9799 9833

Fax: +61 (03) 9799 9033

sales@auschem.com.au

[www.auschem.com.au](http://www.auschem.com.au)

### **WARNING:**

**This chemical is formulated  
for industrial use only**

Contact with skin or clothing or other improper handling or use of this product may result in bodily harm or other damage. Before using or mixing the contents with other substances, all labels applied to container, the applicable Technical Data Sheet and Material Safety Data Sheet should be read and specific instructions and precautions followed to assure correct use and personal safety.



## HIPHOS

### PRODUCT DESCRIPTION

HIPHOS is a versatile low temperature iron phosphate process which simultaneously cleans and phosphates steel, zinc and aluminium surfaces. It can be applied by spray or immersion.

HIPHOS provides the following advantages:

- a) Phosphates steel, zinc and aluminium
- b) Cleans and phosphates in single operation
- c) Liquid product, suitable for auto dosing
- d) Low temperature operation
- e) Excellent base for paint
- f) For use in 3 stage machines or higher

### BATH MAKE-UP AND CONTROL POINTS

Spray:	20-30 litres of HIPHOS per 1000
litre bath	
Immersion:	40-60 litres of HIPHOS per 1000
litre bath	
Time:	1-5 minutes
Spray Pressure:	100-200 kpa (15-30psi)
Titration:	Spray 4-6
(Bath Pointage)	Immersion 8-15
pH	4.2-5.5
Temperature	45° - 55° Celcius

### BATH TITRATION:

- a) Place a 10ml sample of bath into a conical flask, add 100 ml of D.I. water
- b) Add a few drops of phenolphthalein indication
- c) Titrate with 0.1N SODIUM HYDROXIDE SOLUTION until a permanent pink colour is achieved.
- d) The number of mls of 0.1N SODIUM HYDROXIDE used is the bath pointage.
- e) Add 5 litres of HIPHOS for each millilitre below recommended pointage - per 1000 litre tank volume
- f) pH - should be adjusted using ADDITIVE 35

### RINSING

After HIPHOS treatment work should be rinsed with fresh water. For optimum corrosion protection a PASSIVATOR should be used in the final rinse.

### DRYING

Work should be dried as quickly as possible at a temperature not exceeding 150°C.

● *Bringing the Best Products to the Surface* ●

**Disclaimer:** All statement, technical information and recommendations contained herein are based on tests we believe to be reliable, but the accuracy or completeness thereof is not guaranteed. No statement or recommendation shall constitute a representation unless set forth in an agreement signed by officers of seller and manufacturer. NO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE IS MADE. The following warranty is made in lieu of such warranties and all other warranties, express, implied or statutory. Products are warranted to be free from defects in material and workmanship at the time sold. The sole obligation of seller and manufacturer under this warranty shall be to replace any product defective at the time sold. Under no circumstances shall manufacturer or seller be liable for any loss, damage or expense, direct or consequential, arising out of the use of or inability to use the product. No suggestion for product use or anything contained herein shall be constructed as a recommendation to use any product in infringement of any patent rights and seller and manufacturer assume no responsibility or liability for any such infringement. We recommend prospective users determine the suitability of this product through independent testing before adopting on a commercial scale.

