

## Australian Chemicals & Coatings Pty Ltd

ABN: 92 884 104 142

69 Quantum Close,  
Dandenong South VIC 3175

Ph: +61 (03) 9799 9833

Fax: +61 (03) 9799 9033

sales@auschem.com.au

[www.auschem.com.au](http://www.auschem.com.au)

### WARNING:

**This chemical is formulated  
for industrial use only**

Contact with skin or clothing or other improper handling or use of this product may result in bodily harm or other damage. Before using or mixing the contents with other substances, all labels applied to container, the applicable Technical Data Sheet and Material Safety Data Sheet should be read and specific instructions and precautions followed to assure correct use and personal safety.



## ALUMIGOLD

### CHROMATING PRE-TREATMENT FOR ALUMINIUM AND ITS ALLOYS

ALUMIGOLD is a liquid chemical used in the yellow chromating pre-treatment of aluminium and its alloys prior to liquid or powder painting.

#### ADVANTAGES

- \* Offers excellent corrosion resistance
- \* Guarantees strong adhesion
- \* Permits treated aluminium to be stored for long periods prior to painting

#### **Description**

The process requires using ALUMIGOLD as follows:

ALUMIGOLD is the main product; it is a dark brownish red liquid.  
AG Accelerator is an amber liquid product; it is used as an accelerator.

#### **Process Sequence**

1. ALUMIBRITE
2. Rinse overflowing
3. Rinse overflowing
4. ALUMIGOLD
5. Rinse
6. Rinse (Warm Water 60°C - Optional)
7. Warm Air Dry (Max 80°C - Optional)

#### **Operating conditions**

ALUMIGOLD	10 - 18 g/l(*)
AG ACCELERATOR	1.0 - 1.5 g/l

(\*) For a "new" bath solution, it is suggested 10 g/l. While working, the optimum operating conditions are:

ALUMIGOLD	15 g/l
AG ACCELERATOR	1.5g/l

pH	1.5 - 1.9
Temperature	20-30°C
Free acidity	5.0 - 7.0 ml
Dipping time	1-2 minutes

## ● *Bringing the Best Products to the Surface* ●

**Disclaimer:** All statement, technical information and recommendations contained herein are based on tests we believe to be reliable, but the accuracy or completeness thereof is not guaranteed. No statement or recommendation shall constitute a representation unless set forth in an agreement signed by officers of seller and manufacturer. NO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE IS MADE. The following warranty is made in lieu of such warranties and all other warranties, express, implied or statutory. Products are warranted to be free from defects in material and workmanship at the time sold. The sole obligation of seller and manufacturer under this warranty shall be to replace any product defective at the time sold. Under no circumstances shall manufacturer or seller be liable for any loss, damage or expense, direct or consequential, arising out of the use of or inability to use the product. No suggestion for product use or anything contained herein shall be constructed as a recommendation to use any product in infringement of any patent rights and seller and manufacturer assume no responsibility or liability for any such infringement. We recommend prospective users determine the suitability of this product through independent testing before adopting on a commercial scale.

The final result depends from different conditions:

- \* maintain the suggested operative parameters in a narrow range
- \* type of aluminium used
- \* the type of pre-treatment used before the Chromating process.

### **Maintenance**

Add the chemical according to the consumption and consider that every 10 Kg of ALUMIGOLD requires 1 Kg of AG ACCELERATOR.

### **Consumption**

ALUMIGOLD: 1-2 Kg for 1 ton of treated aluminium

AG ACCELERATOR: 0.06-012 Kg for 1 ton of treated aluminium.

### **TANKS & EQUIPMENT**

Stainless steel (316)

Polythene

PVC

### **Bath solution control**

#### **Method of analysis**

*Determination of ALUMIGOLD*

Reagents required

Hydrochloric acid concentrated.

Potassium Iodide (KI)

Sodium Thiosulphate solution, 0.1N

Starch solution, as indicator

- \* In a 400 ml beaker, pour 10 ml of bath solution and add about 100 ml of distilled water
- \* Add a spoon of potassium iodide and 10 ml of concentrated hydrochloric acid.
- \* Add approx. 0.1gl of starch, the solution turns yellowy black.
- \* Titrate with Sodium Thiosulphate solution 0.1N, until there is a light blue colour change.  
Continuous stirring is needed for accurate results.
- \* Record the titrate used with "A" (ml).

### **Calculation**

$A \times 1.1 = \text{g/l of ALUMIGOLD}$

### **Free acidity**

- \* In a 400 ml beaker, pour 10ml of bath solution and add about 100ml of distilled water.
- \* Add 10 drops of green bromocresol.
- \* Titrate with NaOH 0.1N solution until the solution turns from yellow to green.
- \* Record the ml of titrate used as "B".

"B" corresponds to the free acidity.

Adjust free acidity with ADDITIVE 64 ~ 3.8kg of ADDITIVE 64 per 1000 L of bath will raise the titre by one point.

### **Safety**

ALUMIGOLD contains Hydrofluoric Acid

This solution is acidic and in case of skin/eye contact flush with water for 15 minutes and seek medical attention. Please refer to the Material Safety Data Sheet before using ALUMIGOLD.

Operators should be provided with the usual protective clothing i.e., gloves, goggles, aprons etc.